

# Comfort365

## User Manual Model C365T21WF

Rev A Jan 2017

The Comfort365 is a touch screen programmable thermostat that controls heating, cooling and airflow. The thermostat monitors the upstairs temperature sensor and automatically adjusts the upstairs and downstairs airflow to provide uniform comfort.

The thermostat is WiFi enabled and allows you to operate your thermostat remotely using your smartphone, tablet, laptop or PC.

The energy saving nighttime option uses the upstairs temperature sensor to control heating and cooling calls and increases the upstairs airflow.


The user can manually adjust the airflow on occasions when more airflow is needed upstairs or downstairs.



### User Options and Settings


P.1 Quick Reference	P.5 Temperature Override	P. 5-7 User Options (cont.)
P.2 Setting Up WiFi Access	P.5 Displaying Upstairs Temperature	Turning Nighttime Airflow On or Off
P.3 Setting Up WiFi Connection	P.5 Overriding Automatic Airflow Option	Setting Nighttime Airflow in Heating
P.4 Remote Thermostat Access	P.5 Terminating Automatic Airflow	Setting Nighttime Airflow in Cooling
P.4 Set Time of Day	P.5-7 User Options	Cleaning the Touchscreen
P.4-5 Set System, Fan and Thermostat Mode	Set Schedule	Turning WiFi On or Off
P.5 Changing Setpoint Temperature	Selecting Manual or Auto Airflow	Start Linking WiFi Thermostat

### Quick Reference



# Setting Up WiFi Connection

On your smart phone or personal computer, access WiFi settings to connect to  
Comfort365T21WF\_####  
with #### being a random 4 digit number




## 1. Connecting To Home Network

With your phone WiFi on, go to your web browser and type in the thermostat address where you would normally type a website address.

**192.168.8.2**


This screen will appear.

❗ If you are having trouble connecting, disconnect your smart phone or computer WiFi. Repeat *Start Linking The WiFi Thermostat*.



## 2. Enter User Name

In the "365-US.com" box, enter the Username entered during Account Set Up.




## 3. Select WiFi Network / WiFi Pass Phrase

Use the pull down menu in the "WiFi SSID" box to select your home network from the list of networks that are within range.

Or you can type your home network in the "WiFi SSID" box,

If your WiFi network requires a pass phrase, enter the pass phrase in the "WiFi Pass Phrase" box.

❗ If you are having trouble connecting, disconnect your smart phone or computer WiFi. Repeat *Start Linking The WiFi Thermostat*.




## 4. Advanced Options / Save WiFi Settings


Use Advanced Options only if your network requires advanced settings.

Touch **Save** and the thermostat will attempt to connect to your home network.

Once connected Home on your thermostat will be displayed continuously.



On your smart phone or personal computer, access WiFi settings to reconnect to your home network.



The following instructions will guide you through setting up your Comfort365 for remote access using your home network.

User options and settings are outlined on pages 4-8.


## Setting Up Your WiFi Access

### Set Up Comfort365 WiFi Account

To set up your account, use your web browser and enter

**www.365-US.com**


Select **Register Here** to set up your account.

The image shows the 'Comfort365 Login' screen. It has a black background with white text. At the top, it says 'Comfort365' in red and 'Login' in white. Below this are two input fields: 'Username' and 'Password'. There is a checkbox labeled 'Save Username and Password'. A large blue button labeled 'Log In' is below the password field. At the bottom, it says 'Don't have an account yet? Register Here' in blue. A small copyright notice '© Copyright 2017' is at the very bottom.

Enter your Username and Password (password is case sensitive). Confirm Password. Be sure to record the Username and Password in a safe place for future reference.

Select **Save Username and Password** to save the information for easy login next time.


Touch **Next**.

The image shows the 'Comfort365 Register' screen. It has a black background with white text. At the top, it says 'Comfort365' in red and 'Register' in white. Below this are three input fields: 'New Username', 'Enter Password', and 'Confirm Password'. There is a checkbox labeled 'Save Username and Password'. A large blue button labeled 'Next' is below the confirm password field. A small copyright notice '© Copyright 2017' is at the very bottom.

Account information is optional but recommended.

*Your account data will not be provided to any outside parties.*

Touch **Save** after entering account information.

The image shows the 'Comfort365 Account' screen. It has a black background with white text. At the top, it says 'Comfort365' in red and 'Account' in white. Below this are several input fields: 'First Name', 'Last Name', 'Email Address', 'Street Address', 'City', 'State' (a dropdown menu), 'Zip Code', 'Installer', 'Installer's Telephone', and 'Installer's Email Address'. There is a checkbox labeled 'Send me diagnostic data.' and another labeled 'Send the installer diagnostic messages.' At the bottom are two buttons: 'Save' (pink) and 'Cancel' (blue). A small copyright notice '© Copyright 2017' is at the very bottom.


### Set Up Comfort365 WiFi Account (cont.)

The Account page is displayed.

If you need to edit information, touch **Edit**

If no changes are needed, touch **Back** and return to the Home page.

Your Comfort365 WiFi Account is now set up. Close your browser and proceed with the linking process.


The image shows the 'Comfort365 Account' page. It has a black background with white text. At the top, it says 'Comfort365 Account' in red and white. Below this are several sections: 'Username' (ABCD), 'Password' (Change), 'Name' (Bob Smith), 'Email' (bob@gmail.com, Diagnostic messages Will be sent), 'Address' (123 Oak St. Laguna Hills, CA 92653), 'Installer Info' (Name: John Brown, Telephone: 949-222-2222, Email: john@gmail.com, Diagnostic messages Will be sent). At the bottom are two buttons: 'Edit' (blue) and 'Back' (blue). A small copyright notice '© Copyright 2017' is at the very bottom.

### Start Linking the WiFi Thermostat


This option enables the linking of the C365T21WF to the home's WiFi network using any smart device.

Touch the **UP** key to select On to start the linking sequence.

Touch the **ENTER** key to save the options and return to initiate the linking sequence.

The image shows a thermostat screen. It has a light blue background. At the top, it says 'Loc' in black. Below this is a large digital display showing 'On'. To the right of the display are four buttons: 'UP', 'DOWN', 'ENTER', and 'FAN'. At the bottom are three buttons: 'MENU', 'MODE', and 'FAN'.

During the linking sequence "Home" will blink to indicate the thermostat is trying to link with the home router. Once the thermostat has linked with the home router and the Comfort365 cloud, "Home" will be displayed continuously.

The image shows a thermostat screen. It has a light blue background. At the top, it says 'Upstairs 120', 'Airflow % 100', 'Auto 100', 'Downstairs Day', 'Tu 10:08 AM', 'Home 78', 'Cool Set To 78', 'Schedule Inside', 'COOL', 'SYSTEM', 'AUTO', 'FAN'. At the bottom are three buttons: 'MENU', 'MODE', and 'FAN'.

## Remote Thermostat Access

To access your thermostat remotely, use your web browser and enter


**www.365-US.com**

Enter your Username and Password if not displayed (username and password are case sensitive). Select **Save Username and Password** to save the information for easy log in next time.

Touch **Log In** to access your thermostat.

## Accessing Thermostat

The Home page allows you to view and change settings for your thermostat remotely

Touch the icon  to view or change thermostat settings.

Or, touch **Account Info** to edit your account information.

Or, touch **Log Out** to return to the Log In page.

## View / Change Thermostat Settings

This page allows you to view and, set a number of options including:

View Living Temperature  
View Bedrooms Temperature  
View Equipment Status


Edit Nickname  
Select System Mode  
Auto  
Heating  
Cooling  
Off

Select Thermostat Mode  
Schedule  
Hold/Manual  
Vacant

Select Fan Mode  
Auto (most commonly used)  
Continuous (On)

Adjust the Cooling Setpoint  
Adjust the Heating Setpoint  
Set the Sort Priority

Touch **Back** to return to the Home page.

 Press the touchscreen with your fingertip only, using a firm touch. Do not use a sharp object such as a pen or pencil.

## Set Time and Day

Touch here to change the time and day of the week.

### CHANGE THE HOUR

Touch the **UP/DOWN** keys to change the HOUR. Touch **NEXT** to save the hour and go to change the minute.

### CHANGE THE MINUTE

Touch the **UP/DOWN** keys to change the MINUTE. Touch **NEXT** to save the minute and go to change the day of the week.

### CHANGE THE DAY OF THE WEEK

Touch the **UP/DOWN** keys to change the DAY OF THE WEEK.

Touch **ENTER** to save the day of the week and return to thermostat operation.

## Set System Mode

Touch the **SYSTEM** key to display the SYSTEM MODES - OFF, HEAT, COOL, or AUTO. When HEAT is selected, the heating setpoint is displayed. When COOL is selected, the cooling setpoint is displayed. In AUTO or OFF, the setpoint for the last system call is displayed.

Touch and hold the **SYSTEM** key to select:

- OFF** Heating and cooling systems are off.
- HEAT** Only heating calls are enabled.
- COOL** Only cooling calls are enabled.
- AUTO** Heating or Cooling calls are enabled.

## Set Fan Mode

Touch the **FAN** key to display the FAN MODES - AUTO or ON. AUTO is the most commonly used setting.


Touch **FAN** key to select:

- AUTO** Fan is activated only during heating or cooling calls.
- ON** Fan is continuously on.

## Set Thermostat Mode

Touch the **MODE** key to display the THERMOSTAT MODES - SCHEDULE, HOLD and VACANT.

In SCHEDULE MODE, the setpoint temperature is automatically changed at the scheduled times as long as the SYSTEM MODE is in AUTO. In HOLD MODE, the thermostat uses the temperatures set by the user, ignoring the schedule. In VACANT MODE, the thermostat uses the energy saving Vacant heating and cooling setpoints set by the installer until the mode is changed.



Displays the Mode.

Touch and hold the **MODE** key to select:

### SCHEDULE

Setpoint temperatures are changed at scheduled times defined by the user.

### HOLD


Setpoint temperatures are set by the user. No schedule is used.

### VACANT

Setpoint temperatures are kept at the vacant temperatures set by the installer.

## Changing the Setpoint Temperature

The UP/DOWN keys are used to change the setpoint temperature.




Touch the **UP** key to raise setpoint temperature.

Touch the **DOWN** key to lower setpoint temperature.

An active heating call is indicated by HEAT blinking. An active cooling call is indicated by COOL blinking.

To display the opposing system setpoint, touch the area shown below.




Touch here to display and change the opposing setpoint temperature.

Touch the **UP/DOWN** keys to change the setpoint temperature for the opposing system. The thermostat will return to displaying the active setpoint after about 30 seconds.

## Temperature Override

If the thermostat is in SCHEDULE MODE, the setpoint temperature can be overridden using the UP/DOWN keys. The setpoint temperature will be held for 3 hours. After 3 hours the thermostat returns to normal operation.




Touch the **UP/DOWN** keys to adjust the setpoint temperature.

After 3 hours, the thermostat returns to normal thermostat operation.

## Displaying the Upstairs Temperature

The thermostat displays the downstairs temperature and is indicated by INSIDE. The upstairs temperature will be indicated by INSIDE2. In Night Mode, the thermostat displays the upstairs temperature, indicated by INSIDE2.




To display the upstairs temperature, touch the INSIDE temperature as indicated. The thermostat will now display the upstairs temperature, indicated by INSIDE2.

After about 30 seconds, the thermostat will return to displaying the downstairs temperature.

## Overriding Automatic Airflow

In AUTOMATIC AIRFLOW MODE, the user can override the airflow to the upstairs and downstairs by pressing **AIRFLOW %** in the area shown and then use the **UP/DOWN** keys to adjust the airflow. After 3 hours, the thermostat returns to automatic operation. UPSTAIRS, AIRFLOW% and DOWNSTAIRS blink when in airflow override.



Touch **AIRFLOW%** as shown.


Touch the **UP** key to increase the upstairs airflow (the downstairs airflow will automatically decrease). Touch the **DOWN** key to increase downstairs airflow (the upstairs airflow will automatically decrease).

This area will blink when in airflow override.

The override range is defined by the installer during set up.

## Terminating Airflow Override

AIRFLOW OVERRIDE can be terminated by pressing **AIRFLOW %** in the area shown and then pressing the **Mode** key. The thermostat returns to automatic airflow control. The AIRFLOW % returns to the airflow prior to the override.



Touch **AIRFLOW%** as shown.

Touch the **MODE** key to terminate airflow override.

The thermostat returns to automatic airflow control. The AIRFLOW % returns to the airflow prior to the override.

## User Options

- Set Schedule
- Selecting Manual or Auto Airflow
- Turning Nighttime Airflow Option On or Off
- Setting Nighttime Airflow in Heating
- Setting Nighttime Airflow in Cooling
- Cleaning the Touchscreen
- Turning WiFi On or Off
- Linking WiFi Thermostat


## Factory Set Schedule

The thermostat comes pre-set with the following energy-saving schedule for weekdays (Monday-Friday) and weekends (Saturday-Sunday). Using these settings can reduce your heating/cooling expenses.

Monday through Friday	Time	Heat	Cool
Morn	6:00 AM	70	75
Day	8:00 AM	62	83
Even	6:00 PM	70	75
Nite	10:00 PM	62	78
Saturday and Sunday	Time	Heat	Cool
Morn	6:00 AM	70	75
Day	8:00 AM	62	83
Even	6:00 PM	70	75
Nite	10:00 PM	62	78


## Change Factory Set Schedule

Touch the **MENU** key to display SCHEDULE. Here you will select either the weekday or weekend schedule to display or change.




### SELECTING THE WEEKDAY OR WEEKEND SCHEDULE

Touch the **UP** key to select the weekday schedule (MoTuWeThFr) or touch the **DOWN** key to select the weekend schedule (SaSu) and then touch **NEXT**.




### SETTING THE MORNING SCHEDULE START TIME.

Touch the **UP/DOWN** keys to change the Morning Schedule Start Time and then touch **NEXT**.



### SETTING THE MORNING SCHEDULE HEATING TEMPERATURE.

Touch the **UP/DOWN** keys to change the Morning Schedule Heating Setpoint and then touch **NEXT**.



### SETTING THE MORNING SCHEDULE COOLING TEMPERATURE.


Touch the **UP/DOWN** keys to change Morning Schedule Cooling Setpoint and then touch **NEXT**.

Continue setting the start times, heating setpoints, cooling setpoints for the Day, Evening and Night schedules.

Touch **ENTER** to save the schedules to the weekdays or the weekend.

## Selecting Manual or Auto Airflow

This option is only displayed if your installer enabled Manual Airflow Control during installation. AUTOMATIC AIRFLOW is the default. In AUTOMATIC AIRFLOW CONTROL, the airflow is adjusted by the thermostat. In MANUAL AIRFLOW CONTROL, the user must adjust the airflow. The airflow range is defined by the installer during set up.




Touch the **MENU** key until the following thermostat screen is displayed.

Touch the **UP** key to select AUTO. Touch the **DOWN** key to select MANUAL.

Touch the **MENU** key to save and go to next option or touch the **ENTER** key to save the options.

## Turning Nighttime Airflow Option On or Off

When bedrooms are located upstairs, the NIGHTTIME AIRFLOW option can be used to save energy. The thermostat uses the upstairs temperature sensor for controlling heating and cooling calls, as if the thermostat has been moved upstairs. The airflow downstairs is reduced and the upstairs airflow is increased.




Touch the **MENU** key to display NIGHTTIME AIRFLOW option indicated by nAF On or Off.

Touch the **UP** key to turn the option ON. Touch the **DOWN** key to turn the option OFF.

Touch the **MENU** key to save and go to next option or touch the **ENTER** key to save the options.

## Setting the Nighttime Airflow in Heating

This option enables the user to set the maximum allowable upstairs airflow in heating DURING NIGHTTIME OPERATION, not to exceed the installer set maximum allowable upstairs airflow in heating.




Touch the **MENU** key to display NIGHTTIME, UPSTAIRS AIRFLOW IN HEATING indicated by nAF Heat.

Touch the **UP/DOWN** keys to adjust the airflow.

Touch the **MENU** key to save and go to next option or touch the **ENTER** key to save the options.

## Setting the Nighttime Airflow in Cooling

This option enables the user to set the maximum allowable upstairs airflow in cooling DURING NIGHTTIME OPERATION, not to exceed the installer set maximum allowable upstairs airflow in cooling.



Touch the **MENU** key to display NIGHTTIME, UPSTAIRS AIRFLOW IN COOLING indicated by nAF Cool.

Touch the **UP/DOWN** keys to adjust the airflow.


Touch the **MENU** key to save and go to next option or touch the **ENTER** key to save the options.



## Cleaning the Touch Screen

This option disables the touch screen for 30 seconds to enable the user to clean the touch screen by wiping down with a soft, damp cloth.


The CLEAN DISPLAY option indicated by CL. The timer will count down and return to normal thermostat operation after 30 seconds. The remaining time is displayed on the screen.



Touch the **MENU** key to display CLEAN DISPLAY option indicated by CL.


Press **ENTER** to start the 30 second count down. The touch screen is disabled during this time.

Or, press **NEXT** to return to normal thermostat operation




## Install Two AA Batteries

The batteries power the clock when 24VAC power is lost. Slide the battery cover downward and install the two AA batteries as shown.



## Turning WiFi On/Off

This option enables the user to turn WiFi access on or off at anytime.




Touch the **UP/DOWN** keys to turn the WiFi on or off.

Touch the **MENU** key to go to next option or touch the **ENTER** key to save the options and return to normal thermostat operation.


## Start Linking the WiFi Thermostat

This option enables the linking of the C365T21WF to the home's WiFi network using any smart device.



Touch the **UP/DOWN** keys to select On to start the linking sequence.

Touch the **ENTER** key to save the options and return to initiate the linking sequence.



During the linking sequence "Home" will blink to indicate the thermostat is trying to link with the home router. Once the thermostat has linked with the home router and the cloud "Home" will be on continuously.



Learn more about your  
Comfort365 Thermostat  
by watching the Consumer  
How-To Video available at  
[eControlsUSA.com](http://eControlsUSA.com)

### Warranty

This thermostat is warranted to be free of defects due to workmanship or materials under normal use and service for a period of 5 years from date of installation and not longer than 6 years from manufacturing date code.

**eControls**

eControls, 26072 Merit Circle #110, / Laguna Hills, CA 92653  
949-916-0945 [www.eControlsUSA.com](http://www.eControlsUSA.com)